



RECOMMENDED WIRING HOOK UP FOR HONEYWELL L4081B DUAL AQUASTAT

(Standard on the Glenwood Boilers)



HOOK UP FOR HIGH LIMIT AQUASTAT (Activates primary* circulator on temp. rise)



*The primary circulator is the circulator which distributes the water to the radiators or heaters. Where zone valves are used, always use the zone which has the most poten-