




## High Valley 1600 Wiring Diagram



### POWER CORD

Exits stove from Switch Bracket and connects to 120v AC current. Black is “hot”, White is “neutral”, and Green is “ground”.

### RHEOSTAT (Part # RHESTA)

Located on Switch Bracket and turns variable fan speed from High to Low and clicks Off. Has two wires exiting back, with one wire taking power from Power Cord and other wire putting power into Fan Blower.

### FAN BLOWER (Part # BLO1600)

Mounts on back of stove and has two wires exiting housing. One wire is coupled with White “neutral” from Power Cord while the other wire connects to the Rheostat for power. Both wires work with either connection.

### NOTE

*The 1600 Blower Kit is an option that can be installed by either dealer or end user. Blower is mounted on back of stove, while the Switch Bracket with Rheostat can be located in multiple locations; final mount location is at installer's discretion.*

Replacement parts are available at [www.highvalleystoves.com](http://www.highvalleystoves.com)

Technical support is available: **(1)** Call your local dealer, **(2)** Email [sales@highvalleystoves.com](mailto:sales@highvalleystoves.com), or **(3)** Call 800.421.0771.