

HOW TO ACCESS FUSES	Document #		Model Name and Number		
	HT00153-A		OSBURN 2500 (OP00025)		
	Document Version		Serial Number		Date
	01		100	to	...
					29-11-2017

WARNING



NEVER MANIPULATE OR REPLACE A COMPONENT WHEN THE STOVE IS HOT.


DANGER




DISCONNECT ALL SOURCE OF POWER BEFORE MANIPULATING OR REPLACING A COMPONENT.

For part numbers visit our web site <https://www.osburn-mfg.com/en/replacement-parts/> For more information, contact us at 418-908-8002 or by email at tech@sbi-international.com


TOOL(S) REQUIRED :




PROCEDURE :




3




4




5




6



7



8



9

LETTER	FUSES FONCTIONS
A	Control circuit
B	Combustion blower
C	Convection blower
D	Exhaust blower
E	Auger
F	Igniter
G	Main fuse

